

**СПИСЪК НА ЛАЗЕРНИ ПРИНТЕРИ HP LaserJet
МОНОХРОМНИ ЛАЗЕРНИ ПРИНТЕРИ**

Таблица 1

Година на производство	КЛАСОВЕ ПРИНТЕРИ							
	1	2	3	4	5	6	8	9
1996	5L,6L			4, 4+,5	5Si			
1997	5p,6p			4000	5000		8000	
98-2000	1100	2100		4100				
2002	1150	2200		4200				9000
	1200			4300				
2003-2006	1160	2300			5100		8150	
	1300	2420		4200			8150n	
	1320	2430		4300			8150dn	
2007-2008	1010	P2015	P3005	4250				9040n/dn
	1015			4350				9050n/dn
	1022							
2009-2010	P1005	P2035	P3015	P4014	5200			
	P1006	P2055/d		P4015	5200tn			
	P1505	P2055dn		P4515	5200dtn			
2011-2012	P1102/w		P3015d					
	P1566		P3015dn	Ent 600 M601n				
	P1606dn		P3015x	Ent 600 M601dn				
				Ent 600 M602n				
				Ent 600 M602dn				
				Ent 600 M602x				
				Ent 600 M603n				
				Ent 600 M603dn				
			Ent 600 M603xh					

ЦВЕТНИ ЛАЗЕРНИ ПРИНТЕРИ

Година на производство	КЛАСОВЕ ПРИНТЕРИ							
	1	2	3	4	5	6	8	9
98-2000	1500			4550			8500	
2002		2500	3550	4600				
2003-2006	1600	2550	3700	4650			8550	
								9500
2007-2008		2600	3800	CP4005	5500n/dn			
					5500hdn			
		2605			5500dtn			
2009-2010	CP1215	CP2025	CP3525	CP4700	5550			
			CP3525n		5550n			
		CP2025n	CP3525dn		5550dn			
2011	CP1025		CP3525x	Ent CP4025n/dn	CP5225	CP6015dn		
	CP1025nw	CP2025dn			CP5225n	CP6015xh		
2012	CP1525n		Ent 500 CM551n	Ent CP4525n	CP5225dn			
	CP1525nw		Ent 500 CM551dn	Ent CP4525dn				
	CP1525nw		Ent 500 CM551xh	Ent CP4525xh	Ent CP5525n			
	CP1525nw				Ent CP5525dn			
					Ent CP5525xh			

актуални модели